

How to set FTP?

FTP setting:



The image shows a screenshot of an FTP settings dialog box with a light blue background. The title 'FTP' is in red. The fields are as follows:

Server Address:	<input type="text" value="hichip.3322.org"/>
Server Port:	<input type="text" value="1234"/>
User name:	<input type="text" value="hi11"/>
Password:	<input type="password" value="••••"/>
Passive mode:	<input type="radio"/> On <input checked="" type="radio"/> Off
Path:	<input type="text" value="/1231"/>
Test FTP settings:	<input type="button" value="Test"/> Please set first, and then test.

At the bottom, there are two buttons: 'Apply' and 'Cancel'.

Note: If using FTP function, you need to apply the user name and password from FTP Server firstly, and apply a certain storage space at the same time, also asking the user have authority to write and build sub-directory to storage space.