

How to set up micro SD card & All —day and motion detection recording and how to play back the recordings

First, please make sure you connect the camera successfully. If have any problem in its connection, please contact US (service@ieGeek.com).

Second, please make sure that you inset in the micro SD card (Please make sure the micro sd card you used is a genuine brand with class 10).


Here is video tutorial about how to insert in the micro SD card: https://www.youtube.com/watch?v=4QSza5o55VE






a. Plan recording:

2 . Click "Recording Schedule".




3.Turn on the "Enable Record"




b. Motion detection recording:

4. "Setting" - "Alarm Setting" - "Motion Detection"




5. Return to "Setting" - "Action With Alarm", Turn on the "Alarm SD REC"




c. Playback the recording:

6. Click "Video" - "online" - "Camera UID" - "Search"



Online: All the recording (motion detection recording and all-day recording) will be saved to micro SD card, and you can play back it from Online.

Local: All the manually recording and snapshot will be saved to your phone or PC, and you can find it on Local.











Search time interval

2017-12-04 18:43:48 - 2017-12-05 00:43:48

2017-12-05 00:28:24 - 00:28:38

Alarm Recording 00:00:14 1 MB

2017-12-05 00:26:54 - 00:28:24

Plan Recording 00:01:30

5 MB

2017-12-05 00:26:39 - 00:26:53

Alarm Recording 00:00:14

1 MB

2017-12-05 00:15:12 - 00:26:39

Plan Recording 00:11:27 34 MB

2017-12-05 00:00:00 - 00:15:12

Plan Recording 00:15:12

39 MB

2017-12-04 23:56:36 - 23:59:59

Plan Recording 00:03:23 7 MB



2017-12-04 23:56:20 - 23:56:35

Alarm Recording 00:00:15

1 MB

